



TREE CLASSICS

The World's Finest Artificial Christmas Trees



1.

Invert both the tree stand and the Tree-Saver™ bag.



2.

Attach the tree stand to the bag using Velcro straps.



3.

Turn the bag/stand assembly upright.



4.

Insert the tree into the stand and secure.

Tree-Saver™ Upright Storage Bag

A fast and simple solution for storing your Tree Classics hinged tree!



5.

Your tree is now ready for display throughout the holiday season.

6.

To store the tree, remove all your decorations, open the bag (still attached to the tree stand and tree) and pull the bag up to safely enclose branches. It's ready to store until next Christmas.

